

FAQ's

Q: How do I get into program mode.

A: To get into program mode use the following steps:

1. From the 5230 remote Annunciator press 27 then ENTER.
2. Enter the INSTALLER CODE or 5128

Programming with the 5230 Remote Annunciator

NOTES: The system will automatically time out of programming mode if no keys are pressed for four minutes. If you press function keys very quickly, you may get ahead of the LCD display. Wait for the appropriate message to be displayed before you press **ENTER**.

| TO: | KEYSTROKES: |
|---|--|
| ENTER PROGRAMMING MODE | <p>2 7 ENTER [Installer's Code]</p> <p>The first line of the LCD will show the programming option for Step 1, "ZONE ACTIVE." The second line will show the most recently programmed value for that option.</p> |
| PROGRAM AN OPTION | Type in your new data and then press ENTER . |
| SKIP A STEP | <p>Press ENTER.</p> <p>The data in the skipped step will not change. The LCD will show the next option.</p> |
| GO TO A SPECIFIC STEP | <p>Press STEP. The first line of the LCD will show "ENTER THE STEP #" and the current step number. Type in the new step number, then press ENTER. Line 1 of the LCD will show the option name; line 2 will show the programmed data for the step. (If you try to go to a step that does not exist, the display will go back to the previous step.)</p> |
| SELECT YES OR NO | Press any digit to toggle Yes and No. |
| SELECT AN OPTION FROM A MENU | Press the option number. (Option numbers appear next to the option name in Section 5.3.) |
| ENTER ALPHABETIC DATA OR NUMBERS LARGER THAN 9 | <p>SHIFT 1 for A or 10</p> <p>SHIFT 2 for B or 11</p> <p>SHIFT 3 for C or 12</p> <p>SHIFT 4 for D or 13</p> <p>SHIFT 5 for E or 14</p> <p>Note that only the alphabetic characters appear on the display.</p> |
| CORRECT AN ERROR (If you have not pressed the ENTER key.) | Press CLEAR . Then type in the correct data and press ENTER . |
| LEAVE PROGRAMMING MODE AT ANY TIME | Press STEP STEP CLEAR CLEAR . |